



### NOTES

1. Curb Inlet Casting to be as shown on Standard Drawing AA-S126.
2. Place standard 4" curb drain stubs at 30" below the top of the curb or as directed.
3. Install Standard Steps AA-S119 as shown.
4. Plaster coat of lime cement mortar .5" thick. Bricks shall be laid in 1:2 cement mortar.

This Drawing Previously AA-S47.

 STORMWATER PROGRAM MANAGER	
 ADMINISTRATOR	
12/15/93 APPROVED	REVISED

### STANDARD CURB INLET MANHOLE

CITY OF COLUMBUS		
DEPARTMENT OF PUBLIC UTILITIES		
DIVISION OF SEWERAGE & DRAINAGE		
STANDARD CONSTRUCTION DRAWING		
DR. CAW	SHEET 1	FILE NO.
CK. DJH	OF 1	AA-S121